

<b>Adjustment</b>	<b>Loose Off Power “Corner Entry”</b>	<b>Loose on Power “Corner Exit”</b>	<b>Push Off Power ”Corner Entry”</b>	<b>Push On Power “Corner Exit”</b>	<b>Push Neutral Power “Mid Corner”</b>	<b>Loose Neutral Power “Mid Corner”</b>
<b>Front Springs</b>	Stiffen 1st	Stiffen 2nd	Soften 1st	Soften 2nd	Soften	Stiffen
<b>Rear Springs</b>	Soften 2nd	Soften 1st	Stiffen	Stiffen 1st	Stiffen	Soften
<b>Front Shock Oil</b>	Thicker 1st	Thinner	Thinner 1st	Thicker		
<b>Rear Shock Oil</b>	Thinner	Thinner 1st	Thicker	Thicker 1st		
<b>Front Shock Mount</b>	Outer Holes 1st	Outer Holes 2nd	Inner Holes 1st	Inner Holes 2nd	Inner Holes	Outer Holes
<b>Rear Shock Mount</b>	Inner Holes 2nd	Inner Holes 1st	Outer Holes 2nd	Outer Holes 1st	Outer Holes	Inner Holes
<b>Front Sway Bar</b>	Stiffen 1st	Stiffen 2nd	Soften 1st	Soften 2nd	Soften	Stiffen
<b>Rear Sway Bar</b>	Soften 2nd	Soften 1st	Stiffen 2nd	Stiffen 1st	Stiffen	Soften
<b>Front Camber</b>	Less Neg 1st	Less Neg 2nd	More Neg 1st	More Neg 2nd	More Neg	Less Neg
<b>Rear Camber</b>	More Neg 2nd	More Neg 1st	Less Neg 2nd	Less Neg 1st	Less Neg	More Neg
<b>Front Caster</b>	Increase	Decrease	Decrease	Increase	Increase	Decrease
<b>Anti-Squat</b>	Reduce	Reduce	Increase	Increase	Increase	Reduce
<b>Kick-Up</b>	Increase	Reduce	Reduce	Increase	Increase	Reduce
<b>Front Ride Height</b>	Raise	Raise	Lower	Lower	Lower	Raise
<b>Rear Ride Height</b>	Lower	Lower	Raise	Raise	Raise	Lower
<b>Front Role Center (RC)</b>	Decrease Roll- Raise (RC)-1st	Decrease Roll- Raise (RC)-2nd	Increase Roll- Lower (RC) 1st	Increase Roll-Lower (RC) 2nd	Increase Roll-Lower (RC)	Decrease Roll-Raise (RC)
<b>Rear Roll Center (RC)</b>	Increase Roll-Lower (RC) 2nd	Increase Roll- Lower (RC) 1st	Decrease Roll- Raise (RC) 2nd	Decrease Roll- Raise (RC) 1st	Decrease Roll- Raise(RC)	Increase Roll- Lower(RC)
<b>Front Toe Out</b>	Decrease 1st	Increase 2nd	Increase 1st	Decrease 2nd	Decrease	Increase
<b>Rear Toe In</b>	Increase 2nd	Increase 1st	Decrease 2nd	Decrease 1st	Decrease	Increase
<b>Front Droop</b>		Increase		Reduce	Reduce	Increase
<b>Rear Droop</b>	Reduce		Increase		Increase	Reduce
<b>Wheel Base</b>	Lengthen	Lengthen	Shorten	Shorten	Shorten	Lengthen
<b>Front &amp; Rear Axle</b>	Move Both Rear	Move Both Rear	Move Both Front	Move Both Front	Move Both Front	Move Both Rear